



SPACE CREATOR VEHICLE PARTITION

FEATURING BDRH (BIDIRECTIONAL RECESSED HOUSING)

(U.S. Patent No. 8,690,216)

2018+ F-150 POLICE RESPONDER | 2015-2020 FORD F-150 SSV | 2019-2022 F-250

Installation Instructions

Space Creator with High Security/High Visibility Window - 475-1057

Space Creator with Full Window w/ Safety Wire Window - 475-1104

Transfer Kit - 475-1092

Before beginning the installation, confirm that you have received all of the parts for your package.
Read the instructions completely before starting installation.



475-1057

Space Creator Vehicle Partition
with High Security/High Visibility Window
U.S. Patent No. 8,690,216

TOOLS NEEDED:

- Ratchet
- 7/16" Socket
- 10 mm Socket
- T50 Torx Bit Socket



475-1104

Space Creator Vehicle Partition
with Full Window and Safety Wire
U.S. Patent No. 8,690,216

PARTS INCLUDED:

- Hardware Bag with necessary nuts, bolts, etc.



Wings Set



Center HSEP



(2) B Pillar Bracket



Bi-Directional Recessed Housing



(2) Mounting Foot



Begin by removing rear OEM trim cover from outer rail of front seat. Pull trim away from seat rail. Repeat on other side.



Move seats completely forward. Loosen the rear/outer OEM 13mm seat bolt exposed when OEM trim was removed.



Push seat up slightly to slide the Foot Mount Bracket under seat rail, between rail and carpet. Leave bolt loose at this time. Repeat on other side.



Use a small screw driver to pop the lower cover off of the entry assist handle.



Remove 7mm bolt from inside handle. Repeat on other side.



Use provided 5mm hex bolt & spacer to loosely attach B Pillar Bracket, through lower opening in entry assist handle. Repeat for other side.



Install Partition frame into vehicle through PS door and position onto mounting feet.



Lean Partition frame forward and loosely attach B Pillar Brackets to middle hole of frame. Center the partition. Once centered, tighten all hardware at this time.



Loosely attach Center HSEP onto BDRH outside of vehicle using (6) carriage bolts and flange nuts.



Place BDRH with Center HSEP into vehicle. Attach BDRH to Partition Frame using provided carriage bolts and flange nuts. Push carriage bolts in from prisoner side of partition. Tighten all bolts/nuts.



SOLO INSTALL NOTE: Use masking tape over carriage bolts to hold bolt in place while attaching flange nuts from front side of partition.



Install Lower Steel Wing from prisoner side using (3) carriage bolts and flange nuts. Repeat on other side.



Install Upper Poly Wing from officer side using a carriage bolts and flange nuts on the upper and lower hole. Repeat on other side.



Install black caps on all flange nuts.

If you have questions or need further assistance please call Technical Support: 1.877.455.6886



209 W. EASY ST., ROGERS, AR 72756 • JOTTOPUBLICSAFETY.COM • 9/24

Jotto Desk™ is a patented product and Registered Trademark of Assembled Products™ Corporation.
Specifications subject to change without notice.

050-0074-00

