



FLOOR PLATE/DRILL DOWN UNIVERSAL

Installation Instructions

425-6203



1. Remove 20 section of 40/20/40 Seat, if necessary.



2. After removing OEM seat section, locate and wiring to prevent issues. Place Floor Plate on top of transmission tunnel and position as desired.



3. Utilize chosen hardware to secure the Floor Plate to the vehicle floor pan.

If you have questions or need further assistance please call Technical Support: 1.877.455.6886



209 W. EASY ST., ROGERS, AR 72756 • JOTTOPUBLICSAFETY.COM • 9/23

Jotto Desk™ is a patented product and Registered Trademark of Assembled Products™ Corporation.
Specifications subject to change without notice.