




425-6701 WIRING DIAGRAM

Note: A constant red LED on the circuit board indicates improper wiring.
Reverse wiring to correct.



USB Board

*Note: Fuse USB board with 5A fuse.

12V Power Outlet

*Note: Fuse 12v Outlets with 10A fuses.